



Installation instructions





Item	Art. No.	Туре	
1	1007651	Profile 20 anodized	
	1007664	Profile 20 white	
	1007665	Profile 20 black	
2	1007652	LED Module 827	
	1007653	LED Module 830	
	1008062	LED Module 835	
	1007654	LED Module 840	
3	1007669	Connector single White	
4	1007745	End caps silver	
	1007746	End caps white	
	1007744	End caps black	
5	1007672	Diffuser 20 opal	
	1007693	Flex Connector	
















Cable length (1.5 mm²)	7W/m	15W/m	23W/m
1 m	21 m	13 m	9 m
2 m	21 m	13 m	9 m
5 m	20 m	13 m	9 m
10 m	19 m	12 m	8 m
20 m	18 m	11 m	7 m






























































Installation instructions

Cleaning and care

Wipe the luminaire clean using a damp, lint-free cloth. Do not scrub! If heavily soiled, wipe clean with a mild solution of warm soapy water (microfibre cloth and washing-up liquid). Do not use a scouring agent. Do not rub the luminaire dry, as the resulting static may damage the electronic components beyond repair.

Warnings

Installation, commissioning and maintenance may only be carried out by authorized specialist personnel in accordance with these installation instructions and all applicable standards and regulations for the respective area of application. Ensure the electrical, mechanical and thermal suitability of the luminaire for the intended area of application and check that the luminaire is securely fastened after installation. The luminaire is intended solely for lighting purposes; any other use or installation is considered not as intended. Failure to observe the installation instructions may result in the destruction of the luminaire. We reserve the right to make technical changes. The light must be disconnected from the mains before any work is carried out on it. The manufacturer is not liable for damage resulting from incorrect installation, improper operation or unauthorized modifications to the luminaire.




Disconnect the luminaire from the power supply.



Caution, risk of electric shock!



DISPOSAL





To avoid hazards, only LED converters approved by us may be used, otherwise all warranty claims will be invalidated. Exceptions can

be approved by the manufacturer.



- smarterion Triac Power supply units
- Meanwell, HLG
- Tridonic LC/LCA



Light source replaceable by end user.



Control gear can be replaced by a specialist: The transformer must be replaced by a qualified electrician.



Class III luminaires for operation at safety extra-low voltage (SELV)